

Geschwister Schneider Technologie-, Entwicklungs- und Vertriebs UG.

The Geschwister Schneider USB to CAN adapter is a usb device with two galvanically isolated CAN 2.0 A/B controllers. The Device is currently available in two variants; A) stand alone usb device in a rugedised alluminium enclosure, M12 connectors for CAN, and USB B connector. B) in mini pci form factor with pin header for CAN connection.

In either case, communication with the device is realized throught the usb interface. Geschwister Schneider develops and maintains a *Linux SocketCan* driver for the device.

Features:

- Two independant CAN 2.0 A/B channels
- Full per channel Galvanic isolation
- Full ECHO support
- Rugedized option for field environments
- Mini PCI option for system integrators and embedded systems
- Mainline Socket-can Linux driver Kernel Version greater than 3.17
- Gummi-bears on delivery ^_^

SCHNEIDER

1 Quick Start

Under ideal circumstances¹ your distributions maintainers will have included in you distributions release a linux kernel with *Socket-can* support, and the mainline driver for this device *gs_usb*.

In this case make sure the device is connected and enumerates over usb:

\$ sudo lsusb -v -d	1d50:606 f
Bus 004 Device 008:	ID 1d50:606f OpenMoko, Inc.
Device Descriptor:	
bLength	18
bDescriptorType	1
bcdUSB	2.00
bDeviceClass	0 (Defined at Interface level)
bDeviceSubClass	0
bDeviceProtocol	0
bMaxPacketSize0	64
idVendor	<mark>0x1d50</mark> OpenMoko, Inc.
idProduct	0x606f
bcdDevice	1.00
iManufacturer	1 Geschwister Schneider Technologie—, Entwicklungs-
und Vertriebs UG.	
iProduct	2 USB2CAN v1
iSerial	3 2BB144B14435524B41202020FF150B

If necessary load the kernel module for socket-can:

\$ sudo modprobe can_dev

¹Most distributions will include Socketcan as a kernel module

If necessary load the gs_usb kernel module:

\$ sudo modprobe gs_usb

List network interfaces:

```
$ ip link list
...
6: can0: <NOARP,ECHO> mtu 16 qdisc noop state DOWN mode DEFAULT qlen 10
link/can
7: can1: <NOARP,ECHO> mtu 16 qdisc noop state DOWN mode DEFAULT qlen 10
link/can
...
```

Configure and start CAN devices:

```
$ sudo ip link set can0 up type can bitrate 250000
$ sudo ip link set can1 up type can bitrate 250000
```

The CAN interfaces can now be used like any other socket-can interface.

```
$ candump can0
interface = can0, family = 29, type = 3, proto = 1
<0x002> [1] 00
<0x002> [1] 01
<0x002> [1] 02
...
```

2 Usage

The following examples show how to use the ip command and socketcan tools to configure and use the can interfaces.

```
$ ip link set can0 type can help
Usage: ip link set DEVICE type can
         [ bitrate BITRATE [ sample-point SAMPLE-POINT] ] |
         [ tq TQ prop-seg PROP_SEG phase-seg1 PHASE-SEG1
        phase-seg2 PHASE-SEG2 [ sjw SJW ] ]
          loopback { on | off } ]
          listen-only { on | off } ]
         [ triple-sampling { on | off } ]
         [ restart --ms TIME--MS ]
         [ restart ]
        Where :
                 BITRATE
                                := \{ 1..1000000 \}
                 SAMPLE-POINT
                               := \{ 0.000..0.999 \}
                 ΤQ
                                := \{ NUMBER \}
                 PROP-SEG
                                := \{ 1..8 \}
                 PHASE-SEG1
                               := \{ 1..8 \}
                 PHASE–SEG2
                                := \{ 1..8 \}
                 SJW
                                := \{ 1..4 \}
                 RESTART-MS
                                := \{ 0 \mid \mathsf{NUMBER} \}
```

•••

Operating modes

The device can be used in two different operating modes.



Normal mode :

Both the Tx line and the Rx line are connected to the transciever. The controller can transmit, recieve, and acknowledge can frames.

Listen only mode :

The tx line is disconnected from the transciever. The controller can not transmit or acknowledge can frames, but can still recieve can frames acknowledged by others. This mode lets you sniff can traffic.

n

Triple Sampling

Tripple sampling can be usefull in extreamly noisy environments. Bus level sampling is normaly done between the first and second phase segment of a bit time. When tripple sampling is used; three samples are aquired, and a majority vote is used to determin bus level.

\$ ip link set can0 type can tripple-sampling on

3 Kernel module from source

If the target system does support Socket-can but does not yet include the gs_usb driver, the gs_usb kernel module can be compiled from source.

Get the module source fi. via wget

```
$ wget http://schneidersoft.net/resource/USB2CAN/gs_usb_kernel_module_latest tgz
```

Extract the archive

```
$ tar -xzvf gs_usb_kernel_module_latest.tgz
$ cd gs_usb_kernel_module_latest
```

Build and install. Building the kernel module will require the linux build essentials, kernel build environment, and the kernel source files for your kernel.

\$ make
\$./loadmod.sh

4 Firmware update

Firmware upgrade can be performed through usb DFU. To get the device into DFU mode; Make sure the device is unplugged and set the DFU enable jumper by shorting pins PROG and GND. Reconnect the USB cable, and check to make sure the device is in DFU mode.



\$ Isusb

Firmware is flashed to the device using the DFU-Programmer tool from: dfu-programmer.sourceforge.net.

```
$ wget http://schneidersoft.net/resource/USB2CAN/gs_usb_firmware_latest.ihex
$ dfu-programmer uc3c2512c reset
$ dfu-programmer uc3c2512c erase
$ dfu-programmer uc3c2512c flash latest_firmware.ihex --suppress-bootloader-mem
$ dfu-programmer uc3c2512c start
```

Once the new firmware is uploaded. Unplug the device, remove the short, and plug the device in again. You should now see the device and be able to use it.

\$ Isusb

5 Form Factors

Ruggedised Adapter





* Dimensions in mm.

The ruggedized adapter version weighs 120g. 3: Ground 4: CAN-High 5: CAN-Low

Full size Mini PCIe Card





- * Dimensions in mm.
 - 1. DFU connector
 - 2. Channel A indicator
 - 3. Channel B indicator
 - 4. Channel A connector
 - 5. Channel B connector

The Mini PCIe version of the adapter mates with and fits into a standard full size Mini PCIe card slot. Some components, namely those used to implement galvanic isolation, are taller than standard PCIe. Under normal cicumstances these components protrude up and away from the host board without intefering with the host or device operation.

6 Trouble shooting

Problem

Possible Cause/remedy

Device does not enumerate

Device not powered or usb cable damaged.

Driver does not recognize device

Device stuck in DFU mode due to failed DFU process. check lsusb output, and reperform DFU.

LED Indicators

The two dual color LEDs mounted on the device indicate state and traffic according to the following table.

LED A	LED B	Meaning
amber steady	amber steady	device under power. no driver present, usb not enabled.
amber blinking	amber blinking	device under power. no driver present, usb enabled.
Off	Off	device under power. driver present, usb enabled.
green steady	n/a	channel A configured.
n/a	green steady	channel B configured.
red blinking	n/a	channel A successfully sending frames.
n/a	red blinking	channel B successfully sending frames.
green blinking	n/a	channel A successfully recieving frames.
n/a	green blinking	channel B successfully recieving frames.

7 Document revision

Date	Notes
2013.06.08	Initial revision
2013.01.18	Updated DFU pinouts. Added form factor descriptions

Disclaimer: The information in this document is provided in connection with Geschwister Schneider products. No license, express or implied to any intellectual property right is granted by this document or in connection with the sale of Geschwister Schneider products. EXCEPT AS SET FORTH IN GESCHWISTER SCHNEIDER'S TERMS AND CONDI-TIONS OF SALE LOCATED ON GESCHWISTER SCHNEIDER'S WEB SITE, GESCHWISTER SCHNEIDER ASSUMES NO LIABILITY WHATSOEVER AND DISCLAIMS ANY EXPRESS, IMPLIED OR STATUTORY WARRANTY RELATING TO ITS PRODUCTS INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NON-INFRINGEMENT. IN NO EVENT SHALL GESCHWISTER SCHNEIDER BE LIABLE FOR ANY DIRECT, IN-DIRECT, CONSEQUENTIAL, PUNITIVE, SPECIAL OR INCIDEN-TAL DAMAGES (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF PROFITS, BUSINESS INTERRUPTION, OR LOSS OF INFORMA-TION) ARISING OUT OF THE USE OR INABILITY TO USE THIS DOCUMENT, EVEN IF GESCHWISTER SCHNEIDER HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Geschwister Schneider makes no representations or warranties with respect to the accuracy or completeness of the contents of this document and reserves the right to make changes to specifications and product descriptions at any time without notice. Geschwister Schneider does not make any commitment to update the information contained herein. Unless specifically provided otherwise, Geschwister Schneider products are not suitable for, and shall not be used in, automotive applications. Geschwister Schneider's products are not intended, authorized, or warranted for use as components in applications intended to support or sustain life.

© 2013 Geschwister Schneider Technologie-, Entwicklungs- und Vertriebs UG. All rights reserved. Geschwister Schneider logo and combinations thereof are registered trademarks. Other terms and product names may be trademarks of others.